

STAINLESS STEEL MAINTENANCE (EVERY 3 MONTHS)

1) Perform stainless steel maintenance ONCE EVERY 3 MONTHS.

2) Necessary equipment:

- a) Cream Cleaner - Quincy Plus 5000
- b) Spray - Quincy OS 777
- c) Soft microfiber or cotton cloth (4 pieces)
- d) Bottle of water 0.5 liters (water can be replaced with another non-aggressive cleaning agent)

3) Maintenance description:

- a) Using the first cloth and a small amount of water, we clean the entire device from current dirt and grime.
- b) After cleaning the current dirt, we apply a small amount of the product "Cream Cleaner - Quincy Plus 5000" to several different parts of the device.
- c) Using the second cloth, we spread the cream over the entire stainless steel surface of the device.
- d) Wait 10 minutes.
- e) After 10 minutes, we thoroughly wipe the entire device using the third cloth.
- f) Then apply the "Spray - Quincy OS 777" and spray all stainless steel elements of the device.
- g) After a minute, using the fourth cloth, we wipe the entire device.
- h) Ready - repeat after 3 months.