

# Assembly instructions for the device

- 1) Place the main part of the device on a stable surface.**
- 2) Attach the side parts of the device to the base. Use the following for this:**
  - a) 2x Wrench Open-End M17
  - b) 8x Screw M10x30
  - c) 8x Nut M10
  - d) 8x Plastic Cap M10
- 3) Attach the middle part of the device to the side parts. Use the following for this:**
  - a) 1x Wrench Hex Allen 5 mm
  - b) 1x Wrench Open-End M13
  - c) 2x Screw M8x50
  - d) 2x Nuta M8
  - e) 2x Plastic Cap M8
- 4) Attach the device to the ground using one of the 3 mounting methods:**
  - a) Mounting to a hard ground level surface.
  - b) Mounting to a hard below ground level surface.
  - c) Mounting to a concrete foundation below ground level.